

Vantage PRO2™ INSTALLATION DIAGRAM

Anemometer Transmitter Kit

This diagram shows an Integrated Sensor Suite and an Anemometer Transmitter Kit wirelessly connected to a Vantage Pro2™ Console.

