


SEAVIEW

ELEVATE YOUR ELECTRONICS



INSTALLATION INSTRUCTIONS


For Seaview Modular Top Plate:

ADA-R1


Refer to website for most up to
date instructions and videos.

WWW.SEAVIEWGLOBAL.COM


PARTS INCLUDED



X1
(ADAGMT)



X1
(ADAR1P)







5/16-18 x 1"



X8
(516181FHCS)

TOOLS NEEDED



Sudbury Elastomeric Marine Sealant is recommended. To purchase call 800-655-7922 or visit www.seaviewglobal.com





CLOSED DOMES



Hole #	Manufacturer	Model
11	B&G	3G, 4G, HALO20(+), HALO24
12	Furuno	15" - 24" radar domes & SC30
11	Garmin	18" - 24" and Fantom radar domes
8	Geonav	24" radar domes
2	Intellian	C700 (spacers required)
4	JRC	15" radar domes
4	Koden	18" (MDC 900 Series) radar domes RB714A
		15" (MDC 900 Series) radar domes TB715A
10	Koden	25" radar domes, 715A, MDC 900 Series
8	Lorenz	12" - 24" radar domes
5	Lowrance	LR1800HD
11	Lowrance	3G, 4G, HALO20(+), HALO24
10	Nobeltec	15" - 25" radar domes
3	Raymarine	18" - 24" radar domes
11	Raymarine	Quantum and Quantum 2 radar domes
8	Seiwa / Techmarine	12" - 24" radar domes
5	Simrad	18" radar domes (DX64S)
11	Simrad	3G, 4G, HALO20(+), HALO24
5	Sitex	18" (TZ760 / T921) radar domes
10	Sitex	25" radar domes

OPEN ARRAY RADARS

Hole #	Manufacturer	Model
2	Furuno	4' - 6' open array radars
2	Garmin	4' - 6' open array radars
7	Geonav	4' - 6' open array radars
9	JRC	4' - 6' open array radars
1	Koden	4' - 6' open array radars
9	Lorenz	4' - 6' open array radars
9	Lowrance	4' - 6' open array radars
1	Nobeltec	3.5' - 6' open array radars
7	Northstar	4' - 6' open array radars
6	Raymarine	4' - 6' open array radars <i>May need smaller OD washer</i>
7	Seiwa / Techmarine	4' - 6' open array radars
7	Simrad	4' - 6' (RB7 Series) open array radars
3	Simrad	4' - 6' HALO open array radars <i>Requires #ADAHALO3 adapter plate. Drill #3 for adapter plate.</i>
7	Sitex	4' - 6' open array radars


1

Locate the Make and Model of your satellite dome on this chart and determine which drill hole number yours is. Then place the ADA-R1 Drill Template on top of the ADA-R1 and mark the appropriate holes.



2

Drill the four marked holes. Be sure to check with your marine electronic manufacturers manual to determine what size drill bit is needed.




3


Apply marine adhesive sealant along the lip in the center hole on the ADA-R1. Route the cabling through the center hole in the ADA-R1. Then insert through the black rubber grommet.

TIP


Place the connector of the cable into a plastic bag. Apply Vaseline to the exterior of the plastic bag. Then try routing the connector/cable through the black rubber grommet.



4 Be sure that the Top Plate edge sits in the rubber grommet.




5 Make sure that the Top Plate is facing the forward when mounting



OPTIONAL ACCESSORIES


Call 800-655-7922 or visit www.seaviewglobal.com for available accessories.

LIGHT BARS



LTB-R


Fits closed dome radars.



LTB-S


Fits 20" or smaller satdomes.

LIGHT BAR TOPS




LTBP-1197

Perko 1197
Incandescent
Light




LTBP-1697

Perko LED Light.



LTBU1A1197


Light Bar Top
with Perko 1197
Light, can fit GPS.



LTBU1A1697

Light Bar Top
with Perko LED
light, can fit GPS.


SPREADER KIT



SP1-MOD


Allows user to mount GPS
units or antennas onto a
Seaview Modular Mount.

ADA-R1



NOT to scale

Drill Template



The background of the entire page is a light gray topographic map with white contour lines. The lines are irregular and wavy, representing elevation changes across a landscape. The map is centered and covers the entire area.

SEAVIEW//
ELEVATE YOUR ELECTRONICS

SEAVIEW//

Tel: 800-655-7922
www.seaviewglobal.com

EUROPEAN OFFICE

Tel: +33 4 94 53 27 70
www.seaviewprogress.com